


## Live Tuning for Arduino with OcfEmbedded in 15 minutes

Application note



## Table of contents


1	Introduction.....	3
2	Step by step procedure .....	3
2.1	Download and setup.....	3
2.2	Copy Ocf files to Arduino IDE libraries.....	3
2.3	Extract the example.....	4
2.4	Compile and upload the example to your Arduino target .....	5
2.5	Test and enjoy with oStudio LiveTuning.....	7
3	More to do with oStudio and LiveTuning .....	14

## 1 Introduction


Live tuning on embedded targets allows live interaction with embedded applications while they are running. Live debugging allows developers to watch variables states, to trace or set them. Better yet, Live Tuning allows to invoke functions. These functionalities dramatically improve the development and setup phase of any embedded application.

Live Tuning on embedded target is composed of two parts: the embedded code and the oStudio tool. The embedded part of Live Tuning is very simple code to port on the embedded target, mainly by porting the physical layer of the protocol. This application notes provide all the required elements to test OcfEmbedded on Arduino.

Please read the OcfEmbedded programmer guide for more detailed information.



Arduino board



oStudio Live Tuning as live debugger


## 2 Step by step procedure

### 2.1 Download and setup


1. Download and install oStudioLive Tuning from Objectis web site [www.objectis-software.com](http://www.objectis-software.com)
2. Download and open the ArduinoOcfEmbedded\_Application\_Note.zip

### 2.2 Copy Ocf files to Arduino IDE libraries

From the ArduinoOcfEmbedded\_Application\_Note.zip file, folder “libraries” :




extract the folder “Ocfe” to the “Arduino IDE” libraries folder (which is typically [C:\Program Files \(x86\)\Arduino\libraries](C:\Program Files (x86)\Arduino\libraries)) :



### 2.3 Extract the example


From the ArduinoOcf\_Application\_Note.zip file, folder “Example”:




Extract the ArduinoOcf folder to the folder where you usually store your Arduino projects.

## 2.4 Compile and upload the example to your Arduino target


Open the ArduinoOcf.e.ino file with “Arduino Ide”




Select the Board model matching your Arduino



Connect your Arduino to USB port and select the corresponding communication port:




Compile and upload to the Arduino




## 2.5 Test and enjoy with oStudio LiveTuning


1. Once the example is uploaded, the Output 13 Led should blink with a 1 second period.
2. From the Windows start menu, open “oStudio”
3. Select menu File/New/Project




4. In the “Add new project” dialog, select the “Live Tuning” project type, fill in the project name and select the desired folder, then click ok.




5. From the menu “Live Tuning”, select “New connection” :



6. In the “Add New connection” dialog, select “Embedded Com”, this is the communication protocol for Ocf Embedded through a serial “Com” port.



7. In the “Properties” dialog, fill in the appropriate communication parameters :
  - Select the “Com” port corresponding to your Arduino.
  - Select the baud rate “230400” to match the settings in the example program.
  - Click ok.



8. Browse the published variables


All the variables published by the example program through the OCFE protocol are exported in the following section of the source code:

```

ArduinoOcf | Arduino 1.0.5
File Edit Sketch Tools Help
ArduinoOcf
OCFE_BEGIN(ocfEntries)
OCFE_VARIABLE_READONLY(AnalogIn[0], OCFE_TYPE_INT)
OCFE_VARIABLE_READONLY(AnalogIn[1], OCFE_TYPE_INT)
OCFE_VARIABLE_READONLY(AnalogIn[2], OCFE_TYPE_INT)
OCFE_VARIABLE_READONLY(AnalogIn[3], OCFE_TYPE_INT)
OCFE_VARIABLE_READONLY(AnalogIn[4], OCFE_TYPE_INT)
OCFE_VARIABLE_READONLY(AnalogIn[5], OCFE_TYPE_INT)
OCFE_VARIABLE_READONLY(AnalogIn[6], OCFE_TYPE_INT)
OCFE_VARIABLE_READONLY(AnalogIn[7], OCFE_TYPE_INT)
OCFE_VARIABLE_READONLY(DigitalIn[2], OCFE_TYPE_BOOL)
OCFE_VARIABLE_READONLY(DigitalIn[3], OCFE_TYPE_BOOL)
OCFE_VARIABLE_READONLY(DigitalIn[4], OCFE_TYPE_BOOL)
OCFE_VARIABLE_READONLY(DigitalIn[5], OCFE_TYPE_BOOL)
OCFE_VARIABLE_READONLY(DigitalIn[6], OCFE_TYPE_BOOL)
OCFE_VARIABLE_READONLY(DigitalIn[7], OCFE_TYPE_BOOL)
OCFE_VARIABLE_READONLY(DigitalIn[8], OCFE_TYPE_BOOL)
OCFE_VARIABLE_READONLY(DigitalIn[9], OCFE_TYPE_BOOL)
OCFE_VARIABLE(DigitalOut[10], OCFE_TYPE_BOOL)
OCFE_VARIABLE(DigitalOut[11], OCFE_TYPE_BOOL)
OCFE_VARIABLE(DigitalOut[12], OCFE_TYPE_BOOL)
OCFE_VARIABLE(DigitalOut[13], OCFE_TYPE_BOOL)
OCFE_VARIABLE(BlinkPeriod[10], OCFE_TYPE_INT)
OCFE_VARIABLE(BlinkPeriod[11], OCFE_TYPE_INT)
OCFE_VARIABLE(BlinkPeriod[12], OCFE_TYPE_INT)
OCFE_VARIABLE(BlinkPeriod[13], OCFE_TYPE_INT)
OCFE_END;
    
```

The list of published variables can easily be changed to match your own application. See the Ocf programmer guide for more information.

All those metadata are read by oStudio when connecting to the Arduino target (or when F5 key is pressed to refresh the tree). So, once connected to the Arduino, oStudio let you immediately browse all those variables with the left tree view.




While the mouse cursor is moving around a variable name, a tooltip appears displaying the current value of the variable, retrieved through OCFE protocol.

#### 9. Monitor the variables

Simply drag drop a variable from the tree on the left to the watch pane on the right.


The variable is monitored, and the value is continuously updated.



Doing so with the DigitalOutput[13] that is blinking, you will see the toggling of the variable in the watch pane.

10. Remotely change the value of a variable

A double click on any variable will open the “Field invocation” dialog. This dialog will let you type a new value for the variable that will be applied with the “Apply” button.




To test this functionality, you can change the blink period of the digital output 13 by setting a new value to BlinkPeriod[13] (for example, set the value 500 to set the blink period to 500 ms). In this Arduino ocfe example application, setting the blink period to 0 will stop blinking.


In the same way, you can write the value of a DigitalOutput, by writing the corresponding variable.

11. Tracing a variable

A right click in the tabs will let you create new panes.




Create a new trace pane, and simply drag-drop the variables to trace into this new pane.



In the picture above, the variables DigitalOut[13] and AnalogIn[0] are plot.

oStudio let you organize your panes in multiple views :




## 12. Scripting

oStudio offers many additional functionalities, that are extremely useful to tune an application. We will finish by writing a small C# script demonstrating how to write a variable.


Simply create a new pane "CsScript", which let you write some C# code that will be compiled on the fly.

To read or write a variable into the Arduino using Ocf, simply use the path of the variable and read it or write it as usual with the “=” operator. To make this more easy, you can also simply drag drop a variable from the tree to the script pane.

As an example, we will write a script that slowly changes the blinking period from 0 to 500 ms for output 13.



Click on the run button. The blink period will slowly increase from very fast to normal blinking. The result is clearly visible on the Trace below :



Keep in mind that Ocf is dynamic typed, so it is sometimes better or even required with C# scripts to use type cast to ensure proper execution.

The code written as scripts in oStudio can also be integrated into your own plain .Net applications.

To do so, you simply need to download the OcfApi, an extremely easy to use library.

### 3 More to do with oStudio and LiveTuning

Our experience is that oStudio, the live debugging tool, dramatically improves the development efficiency and the tuning of embedded systems.

We wish that you will also get a lot of benefits from oStudio in your own projects.

You can go further with Ocf solutions :

- OcfNative is a communication protocol that let you monitor in the same easy way any of your plain .Net applications. Simply publish your objects with a few lines of code and oStudio let you grab into your application.
- “OcfNative AES encrypted” let you achieve the same results with a high level of security on open networks.
- OcfApi let you very easily integrate Ocf protocols into your own .Net applications in a snap. That way, Ocf is not only a debugging facility, but a first class communication solution.

Ocf is a simple and efficient object oriented communication solution that simplifies to the extreme the interoperability of applications.

OBJECTIS is continuously working on improving oStudio and Ocf to deliver excellent solutions to the community. We will appreciate your feedbacks.

